















Accessories

Description	Article No.	
CT connector Tamper cover for CT locking. Fits over the M12 connector at both sensor and transmitter ends of the remote system cable (2 pcs.)	A5E31478498	
Bag of glands (metric) in black plastic ¹⁾	A5E03907414	
Bag of glands, (metric) in gray plastic Ex e/i ¹⁾	A5E03907424	
Bag of glands (metric) in AISI 316 SS Ex e/i ¹⁾	A5E03907429	
Bag of glands (metric) in Ni-plated brass Ex e/i ¹⁾	A5E03907430	
Bag of glands (NPT) in black plastic ²⁾	A5E03907435	
Bag of glands (NPT) in gray plastic Ex e/i ²⁾	A5E03907451	
Bag of glands (NPT) in AISI 316 SS Ex e/i ²⁾	A5E03907467	
Bag of glands (NPT) in Ni-plated brass Ex e/i ²⁾	A5E03907473	
Standard cable (non-Ex) with M12 connectors, PO insulation and PUR sleeve, gray, -40 ... +80 °C (-40 ... +176 °F)		
<ul style="list-style-type: none"> • 5 m (16.4 ft) • 10 m (32.8 ft) • 25 m (82 ft) • 50 m (164 ft) • 75 m (246 ft) • 150 m (492 ft) 	A5E03914805 A5E03914850 A5E03914853 A5E03914859 A5E03914861 A5E03914874	
Standard cable (non-Ex) for termination, PO insulation and PUR sleeve, gray, -40 ... +80 °C (-40 ... +176 °F)		
<ul style="list-style-type: none"> • 5 m (16.4 ft) • 10 m (32.8 ft) • 25 m (82 ft) • 50 m (164 ft) • 75 m (246 ft) • 150 m (492 ft) 	A5E03914833 A5E03914849 A5E03914854 A5E03914856 A5E03914864 A5E03914873	

Description	Article No.	
Standard cable (Ex) with M12 connectors, PO insulation and PUR sleeve, blue, -40 ... +80 °C (-40 ... +176 °F)		
<ul style="list-style-type: none"> • 5 m • 10 m • 25 m • 50 m • 75 m • 150 m 	A5E03914929 A5E03914962 A5E03914995 A5E03915004 A5E03915074 A5E03915088	
Standard cable (Ex) for termination, PO insulation and PUR sleeve, blue, -40 ... +80 °C (-40 ... +176 °F)		
<ul style="list-style-type: none"> • 5 m • 10 m • 25 m • 50 m • 75 m • 150 m 	A5E03914945 A5E03914973 A5E03914984 A5E03915015 A5E03915057 A5E03915100	
Analog signal cable		
For analog cable connection between MASS 2100/ FC300 sensor and FCT010/030 transmitters. 5 x 2 x Ø 0.34 mm screened and twisted in pairs. Blue PVC insulation and sleeve. With two M20 connectors, female/female. -20 ... 105 °C (-4 ... +221 °F), Ex		
<ul style="list-style-type: none"> • 1 m • 2 m • 5 m • 10 m • 15 m 	A5E42815465 A5E42521862 A5E42522447 A5E42523233 A5E42523347	

¹⁾ 2 pcs M20; 1 pce M25 with single and dual cable inserts





²⁾ 2 pcs ½" NPT; 1 pce ½" NPT with single and dual cable inserts

Flow Measurement







SITRANS F C

Flowmeter - Accessories/Spare parts










Spare parts - sensor FCS400/FCS300

Description	Article No.	
Blind lid in painted aluminum with silicone o-ring seal	A5E03549295	
Sensor housing <ul style="list-style-type: none"> • metric • NPT 	A5E03549313 A5E03906080	
Bag of loose parts for sensor; including cable strain relief components, washer, seals, silicone o-rings, and assorted screws	A5E03549324	
M12 option for sensor housing in stainless steel. Pre-wired and potted to replace M12 socket in DSL housing	A5E03906095	

Spare parts - Transmitter FCT030 Field mount enclosure (all FW versions)










Description	Article No.	
Display lid in painted aluminum with Ex glass plate and silicone o-ring seal Ex and Non-Ex	A5E03549344	
Blind lid in painted aluminum with silicone o-ring seal	A5E03549429	
Bag of loose spare parts; including cable strain relief components, mounting tool, seals and gasket, assorted screws and washers, hex cap nut, blind connectors, and silicone o-rings	A5E03549396	
Mounting bracket - FCT030 field mount; in painted aluminum for pipe or wall mounting of transmitter FCT030 remote version. Including lock ring, pressure pads and seal cap	A5E03906091	
M12 option - remote - in painted aluminum. Pre-wired and potted replacement M12 connection for FCT030 field mount transmitter remote version	A5E03906104	
Remote terminal house painted aluminum for sensor cable termination at FCT030 transmitter remote version. Pre-wired and potted <ul style="list-style-type: none"> • M20 • NPT 	A5E03906112 A5E03906130	

Spare parts - Transmitter FCT030 (FW 3.1)

Description	Article No.	
Display and keypad assembly for field mount enclosure, with Siemens logo. For HW 2 and FW 3.1 version	A5E03548971	
Sensor cassette (Compact) (HW version 2, FW 3.1.X)	A5E03549142	
Sensor cassette (Remote) (HW version 2, FW 3.1.X)	A5E03549098	
Frontend cassette Spare part frontend cassette for remote version of FC430 and cassette for FC410 For firmware V 2.x	A5E03549191	
Power supply for field mount enclosure 100 ... 240 V AC, 47 ... 63 Hz 24 ... 90 V DC (HW version 2 and FW 3.1.x)	A5E03549413	
Transmitter cassette (active) 4 ... 20 mA output and HART 7.2 (HW version 2 and FW 3.1.x)	A5E03549357	
Transmitter cassette (passive), 4 ... 20 mA output and HART 7.2 (HW version 2 and FW 3.1.x)	A5E03549383	
I/O assembly Advise Order code F40 to F97 Selection and Ordering data ¹⁾	A5E03939114	
SensorFlash (micro SD card 1G)	A5E03915258	

¹⁾ The I/O configuration must be stated in the "Remark" field. The I/O configuration is found in the F option of the ordering code. e.g. code "F40" for ordering Ch2 Active Current/Freq/Pulse, Ch3 Active Current/Freq/Pulse, Ch4 Active Input






Spare parts FCT030 - Fieldmount enclosure (FW 4.0)

Description	Article No.	
Display and keypad assembly • From firmware 4.0, with Siemens logo	A5E37705139	
• From firmware 4.0, neutral version - no company logo	A5E39844362	
Power supply for field mount enclosure FCT030 V 4.0 Fieldmount 100 ... 240 V AC, 47 ... 63 Hz 19.2 ... 28.8 V DC	A5E38264471	
Sensor cassette (compact) for systems without DSL and for systems with analog sensor connection, HW version 3, FW version 4.0	A5E41526318	
Sensor cassette (remote) Ex barrier module digital sensor connection (HW version 3, FW version 4.0)	A5E03549098	
Sensor cassette (remote) for systems with DSL, HW version 3, FW version 4.0	A5E03549098	
Frontend cassette Spare part frontend DSL for remote version . For firmware V 4.0	A5E41526286	
SensorFlash (micro SD card 4G)	A5E38288507	
Transmitter cassette for firmware 4.0 • Ch1 E02: I/O and comm (active/passive) 4 ... 20 mA output and HART 7.5, Non-Ex • Ch1 E06: I/O and comm (active) 4 ... 20 mA output and HART 7.5, Ex • Ch1 E07: I/O and comm (passive) 4 ... 20 mA output and HART 7.5, Ex • Ch1 E10: Communication PROFIBUS PA, Non-Ex & Ex • Ch1 E11: Communication PROFIBUS DP, Non-Ex • Ch1: Communication Modbus RTU 485, Ex • Ch1: Communication Modbus RTU 485, Non-Ex	A5E38013040 A5E38012278 A5E38013025 A5E41216315 A5E41216042 A5E38013054 A5E38013069	









Flow Measurement

SITRANS F C

Flowmeter - Accessories/Spare parts

Description	Article No.		Description	Article No.	
IO Cassette for firmware 4.0			Adapter cable for FCS400 sensor with new transmitter DSL/FCT010/FCT030 Version 4.0	TBD	
• Ch2: Current/Frequ./Pulse, Ch3: None, Ch4: None F01, Non-Ex	A5E38006256		Remote adapter for wall bracket M20 cable connection		
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: None, F02, Non-Ex	A5E38006558		• Ex	A5E42404417	
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: Current/Frequ./Pulse F03, Non-Ex	A5E38006598		• Non-Ex	A5E42846478	
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: Relay, F04, Non-Ex	A5E38006896		Wall bracket for FCT030 for M20 analog cable connector	A5E42404426	
• Ch2: Current/Frequ./Pulse, Ch3: Relay, Ch4: Relay, F05, Non-Ex	A5E3800690		Wall bracket for FCT010 for M20 analog cable connector	A5E42404447	
• Ch2: Current/Frequ./Pulse, Ch3: Relay, Ch4: None, F06, Non-Ex	A5E38011432		Compact adapter for DSL/FCT030 For upgrade from MASS 2100 DI3, DI6, DI15 with MASS 6000 compact to DSL/FCT030		
• Ch2: Current/Frequ./Pulse, Ch3: None, Ch4: None, F11, Ex-passive	A5E38011478		• Ex	A5E42846758	
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: None, F12, Ex-passive	A5E38011509		• Non-Ex	A5E42846760	
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: Current/Frequ./Pulse, F13, Ex-passive	A5E38011541		Compact adapter for DSL/FCT030 FCS300 and FCS400 (DN 100 and DN 150 sensor) adapter for compact mount DSL, FCT010 or FCT030 Ex and Non-Ex	TBD	
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: Relay, F14, Ex-passive	A5E38011600				
• Ch2: Current/Frequ./Pulse, Ch3: Relay, Ch4: Relay, F15, Ex-passive	A5E38011618				
• Ch2: Current/Frequ./Pulse, Ch3: Relay, Ch4: None, F16, Ex-passive	A5E38011908				
• Ch2: Current/Frequ./Pulse, Ch3: None, Ch4: None, F21, Ex-active	A5E38012039				
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: None, F22, Ex-active	A5E38012056				
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: Current/Frequ./Pulse, F23, Ex-active	A5E38012121				
• Ch2: Current/Frequ./Pulse, Ch3: Relay, Ch4: Relay, F24, Ex-active	A5E38019235				
• Ch2: Current/Frequ./Pulse, Ch3: Current/Frequ./Pulse, Ch4: Relay, F25, Ex-active	A5E38019263				
• Ch2: Current/Frequ./Pulse, Ch3: Relay, Ch4: None, F26, Ex-active	A5E38019378				

Spare parts - FCT030 Wall mount enclosure

Description	Article No.	
Display and keypad assembly <ul style="list-style-type: none"> For wall mount enclosure, Siemens logo 	A5E37697615	
<ul style="list-style-type: none"> For wall mount enclosure, neutral version 	A5E39844261	
Power supply for wall mount 100 ... 240 V AC, 47 ... 63 Hz 19.2 ... 28.8 V DC	A5E38263021	
Sensor cassette for FCT030 wall mounting enclosure	TBD	
Foam insert set for wall mount with connectors	A5E38287828	
Wall mount enclosure front blind, Siemens version	A5E38287882	
Wall mount enclosure front blind, Neutral version - no company logo	A5E38287965	
Wall mount enclosure front with glass	A5E38288007	
Wall mount enclosure bracket for pipe mounting	A5E38288020	
Wall bracket panel mounting	A5E38288032	
Bag of loose spare parts for wall mount including cable strain relief components, mounting tool, seals and gasket, assorted screws and washers, hex cap nut, blind connectors and O-rings	A5E38288072	
Metal kit PSU cover back pane for wall mount enclosure	A5E38415145	

Description	Article No.	
Power input cover plate for wall mount enclosure	A5E38415205	